



## O-RING RETRODRAIN INSTALLATION INSTRUCTIONS

**For Use With:** All types of roof covers.

**Application and Instructions:** A retrofit drain option where standard sizes are not available. Prior to installation, the water leader should be cleaned of all asphalt and debris. During installation, the O-rings should be placed toward the bottom of the drain stem. Sealant or caulking should be applied all around the O-rings as well as the entire stem in large amounts to ensure watertight installations.

**Available Sizes:** The O-Ring RetroDrain is a custom made product and can be made to fit most drain pipe diameter applications ranging from 1" to 12". Most sizes are available in RAC and OlyFlow designed drains.

**For technical assistance  
contact OMG at 800-633-3800.**



153 BOWLES ROAD  
AGAWAM, MA 01001  
800-633-3800  
WWW.OLYFAST.COM

