

BeadPro - Hoses Assembly Instructions

Please read and understand all instructions



1- Install Hoses into the four hose holders on the BeadBar. The hose will extend through the bottom of the BeadBar 1-in.



3- Very Important - Apply grease to black rubber O-ring on the applicator.



5- Connect adhesive applicator to mixing tip with a quarter turn. Place applicator in holster.

2- Very Important - Connect secondary mixing nozzle to mixing tip, push to third rib. **Make sure final seating position of Quick Connect is at 3rd Rib.**



4- Slide mixing tip and hose up through the bottom of the applicator holster.



You are now ready to apply adhesive.